

Part number: do88-kit74

## Volvo 850/SVC70 Turbo 3'' inlet hose / do88-kit74



### Step 1:

This turbo inlet hose is adapted for 70mm inlet on the turbo. If you want to use this hose with the 60mm OEM turbo simply tighten then hose to down to 60mm with the included hose clamp.

### Step 2:

For the hose to sit properly on the turbo it will have to be modified a little. A small piece of silicone has to be cut away to make clearance for the wastegate screw boss. Hold the hose against the turbo inlet And mark with pen where to cut.

About 10x5mm, use a switch blade knife, Be careful!



### Step 3:

The inlet hose is prepared for external BOV recirculation. If you use the OEM BOV cover this connection with the included 25mm plug and hose clamp.

### Step 4:

Except the BOV connection this inlet hose has four more hose connections. The larger connection (25mm) is for the crankcase ventilation heater / sensor. The other three connections are for vacuum hoses. All three connections are not used on all year models, that's why 2 silicone caps are included. Cover those connections that wont be used with these caps. Connect the vacuum hoses with the included hose fittings.